

QUICK CONNECT GUIDE

DSL INTERNET

WIRELESS MODEM/ROUTER

Your WI-FI PASSWORD is the last 9 characters of the SERIAL NUMBER (S/N) (does not include dashes) found on the BOTTOM of the modem. ALL LOWERCASE.

VIEW OUR HELP VIDEO AT EXECULINK.CA/DSL-WIRELESS-SETUP OR CALL 1-877-393-2854

STEP 1: DOUBLE CHECK

Make sure you have the following components in your High Speed Internet package.

High Speed Modem/Router & Power Adapter

NOTE: You will have either the AR-5312u Modem/Router or the VR-3060 Modem/Router with minor differences in setup.



Ethernet Cord & Telephone Cord




Telephone filter(s) if required



OPTIONAL: CONNECT FILTERS

If you DON'T have a home phone line, you can skip this step.

Place a telephone filter between every device in your home that plugs into a phone jack, except the modem (e.g. telephones, fax machines, and alarm systems—although your alarm system may require its own specific type of filter). The filter plugs into the wall and the devices plug into the filter.



If you're unsure whether you need a filter, call us at 1.877.393.2854.

STEP 2: CONNECT TO MODEM

Connect one end of the grey telephone cord into the grey DSL port in the back of the modem/router and the other end into your wall jack, which should be no further than six feet away.

Please note: Telephone extension cords should not be used to connect the modem/router to the telephone jack.



STEP 3: TURN ON

1. Connect the power adapter to the modem. Turn on the modem and wait up to fifteen minutes while the modem/router downloads software updates.

Please note: It is important NOT to turn off the modem/router while this is happening as it may cause malfunctions.

2. After fifteen minutes the following lights should be lit green on the front panel of the modem/router:

- Power (on)
- WIFI (on or blinking)
- Internet (on or blinking)
- DSL (on)



To customize your wireless settings including password, network names and more, visit execulink.ca/myexeculink.

OPTIONAL: CONNECT TO COMPUTER

If you have a device that can't connect wirelessly, complete this step.

Connect one end of the Ethernet cable to the Ethernet card in your computer and the other end to any one of the yellow Ethernet ports in your modem/router.

Do not plug anything into the ETH WAN (blue) port.



For steps on how to change your WI-FI password, go to www.execulink.ca/change-wifi-password.

NEED HELP?

CALL 1.877.393.2854
VISIT SUPPORT.EXECULINK.CA